



M-POWER-5T-SLIM PLATE

ABOVE SURFACE SLIM PLATE INSTALL GUIDE



CUT HOLE IN WOOD

1

Rout/cut bottom of wood/stone/etc. for outlet as indicated on template labeled "ROUTING TEMPLATE".




INSTALL OUTLET

2

Insert outlet from top, and slip mounting brackets as shown over threaded studs. Screw the four nuts (8-32) onto each of the four studs below the mounting brackets and tighten, locking the outlet in place.



M-POWER-5T-SLIM PLATE





M-POWER-5T-SLIM PLATE

